




AGE GRADE 4 +

This package includes:



Unpacking your ZhuZhu™ City Starter Set

Remove all contents from package and discard any rubber bands, wire ties or other packaging materials that are not part of the product.

Please Note

- Retain these instructions as they contain important information.
- Read all of the instructions before assembling your Starter Set.
- Some adult assembly is required.
- The ZhuZhu™ City Starter Set is a toy. It is not intended for use with live animals.

The Starter Set is made to be used with ZhuZhu™ Hamsters which are sold separately. The Starter Set works best on an open floor.


For more information on the ZhuZhu™ City Starter Set and other ZhuZhu™ add-on sets and accessories please go to:

www.zhuzhupets.com

Assembling your ZhuZhu™ City Starter Set

A. Attaching Turns to the City Room:

Connect Turns to two adjacent doorways on the City Room by using Connectors.




B. Attaching the Ramp to City Room:

Connect the Ramp to one of the 3 entryways by pushing the bottom and sides of Ramp connector to the bottom and sides of the entryway of the City Room.


Placing the Sign:

Attach the Sign to any one of the entrances by positioning the Sign's posts above the matching slots in the playset at the right and left sides of an entrance and pressing down, pushing down until they are a snug fit.




Placing the Trees and Cityscapes:

Attach the Trees or Cityscapes to the playset by inserting the Tree or Cityscape bases into the holes located around the perimeter and top of the playset.




Inserting the Door to the City Room

You can push the Door (entry blocker) into any of the entryways by positioning it inside the doorway (from the inside of the room and on the curved side) and pushing it outwards. It will stop when it can't move any further.




Removing the Door to the City Room

Slide the Door up and out to remove.



Assembling Turns as an S-Curve:

By reversing one of the Turns and using a Connector, you can create an S-Curve track.



The S-Curve needs only one doorway and can be attached to other add-on sets sold separately.

Disassembly

To remove the Ramp or Connector, gently pull apart from the bottom.



Troubleshooting

- Designed to act randomly and unpredictably, your ZhuZhu Pet™ may not act the same each time.
- If your ZhuZhu Pet™ gets stuck entering the Starter Set, check all the snaps and Connector junctions.
- Your ZhuZhu Pet™ works best on smooth, hard, and even surfaces. It will not work in water, carpet, or other soft surfaces. Do not use in sand or grass.
- The Starter Set also works best on smooth, hard, and even surfaces.

- **HAMSTER SOLD SEPARATELY!**
- **DO NOT PUT HAMSTER IN WATER!**
- **KEEP HAIR AWAY FROM WHEELS!**

For Questions and Comments please call:
1-800-225-9319

©2024 Cepia LLC.
St. Louis, Missouri 63124
Made in China



WARNING:

All rubber bands and wire ties, as well as tags, are not parts of this toy and should be discarded for your child's safety. Colors and contents may vary from those shown on the package.

Printed in China
REV T12102009 86650